

FABRICATION AND MEASUREMENTS OF NIS JUNCTIONS TO CHARACTERIZE PLASMA ETCHING

Nicolas PAILLET
Under the supervision of

Pr. Jukka PEKOLA & Quentin RAFHAY

Grenoble INP Phelma



Aalto University



OUTLINE

1 INTRODUCTION

2 THEORY

3 EXPERIMENTAL METHODS

4 EXPERIMENTAL PROTOCOL

5 RESULTS

- Room temperature results
- Low Temperature Measurements

6 CONCLUSION

INTRODUCTION

The PICO Group : Heat transport at low temperature, single-electron counting, redefining the ampere.

Context : Evaporator nicknamed LISA and plasma etching




Picture of the evaporator LISA

THEORY

SUPERCONDUCTIVITY

- Superconductivity
- Cooper pairs




Schematics explaining the cooper pairing

DENSITY OF STATES

- Density of states and NIS junction

$$N(E) = \begin{cases} N_0 \frac{E}{\sqrt{E^2 - \Delta^2}} & \text{if } |E| > \Delta \\ 0 & \text{if } |E| < \Delta \end{cases}$$



Density of states for a junction

- Dynes density of states : leakage current


EXPERIMENTAL METHODS

CLEANROOM PROCESS

Cross section of the wafer during its preparation




Cross-section during evaporation




EXPERIMENTAL METHODS

CLEANROOM PROCESS


- O₂ valve : Oxidation
- Plasma Gun (with Ar valve) :
 - Low power : Resist weakening → Easier Lift-off
 - High Power : Plasma Etching → Etch materials



Normal mode



Secondary electron mode




Failed sample

SEM images of some samples

EXPERIMENTAL METHODS

DILUTION CRYOSTAT




Schematics representing the functioning of a dilution cryostat. In red, ^4He , in blue $^3\text{He}/^4\text{He}$ mixture and in grey, heat exchangers.

EXPERIMENTAL PROTOCOL

SETTINGS

- 4 Pads pattern




Drawings of the pattern used

- 4x5 matrix with 4 Surface areas : 0.5 to 2 by $0.5\mu m^2$ and 5 EBL dose from 2000 to 3000 by $250 c/\mu m^2$
- Development 20s MIBK, 20s Methyglycol, IPA
- Evaporation : Al 20nm, Cu 25nm
- Optionnal : Strong Oxidation (10min, 200mbar), and/or Plasma Etching, and/or Tunnel barrier Oxidation (2min, 2mbar)
- 4 probe measurements with a probestation
- Eventually : Low temperature measurements : I-V


ROOM TEMPERATURE RESULTS

REFERENCE SAMPLES (WITHOUT PLASMA ETCHING)




Strong Oxidation (10min/200mbar)

$$RS = 7198 \Omega \cdot \mu\text{m}^2$$



Clean Contact Al + Cu

$$R = \sum_{Cu,Al} \frac{\rho l}{S} \simeq 78 \Omega$$




Tunnel junction (2min/2mbar)

$$RS = 763 \Omega \cdot \mu\text{m}^2$$

ROOM TEMPERATURE RESULTS

POSITION OF THE SAMPLE

- Samples with Strong Oxidation, Plasma etching 10 min, Clean contact, before the Oxygen Cleaning.





⇒ Plasma is homogeneous & 10min seem enough to etch the Oxide
 No surface dependance, same order of magnitude as clean contact.

ROOM TEMPERATURE RESULTS

DURATION OF THE PLASMA ETCHING

- Samples with Strong Oxidation, Plasma etching, Clean contact.
- Before the Oxygen Cleaning
- After the Oxygen Cleaning





⇒ Similar results for totally different parameters before and after the cleaning. Before → 10 min of Plasma was a good time. After the cleaning → less than 5 min is enough & 10 min is too much.

ROOM TEMPERATURE RESULTS

PLASMA PROBLEMS

- Samples with Strong Oxidation, Plasma Etching 10 min , Tunnel barrier.
- Before Oxygen Cleaning
- After Oxygen Cleaning





⇒ Exact same parameters, before the cleaning : resist burned,
after the cleaning : unidentified areas.

ROOM TEMPERATURE RESULTS

WAFER ETCHING

- Sample with Strong Oxidation, Plasma Etching 10 min, Tunnel barrier, after Oxygen Cleaning.




SEM images with a tilted angle : The darkest area is a hole in the wafer

LOW TEMPERATURE MEASUREMENTS

TUNNEL BARRIER BEFORE OXYGEN CLEANING

- Sample with Tunnel barrier (NIS) without Plasma




Current in function of bias voltage applied

- Leakage $\simeq 10^{-4}$ \rightarrow Correct junction

LOW TEMPERATURE MEASUREMENTS

TUNNEL BARRIER WITH PLASMA ETCHING

- Sample with Strong Oxidation, Plasma Etching 2min30s, Tunnel barrier, after the Oxygen Cleaning.




Current in function of bias voltage

- Leakage $\simeq 10^{-2}$ The leakage is quite bad but...

LOW TEMPERATURE MEASUREMENTS

TUNNEL BARRIER REFERENCE FOR PREVIOUS SAMPLE

- Sample with Tunnel barrier, after the Oxygen cleaning.



Current in function of bias voltage

- Leakage $\simeq 10^{-2}$ \rightarrow Same order of magnitude for plasma etched sample and reference : something else wrong with the LISA

SUMMARY

- Studied bibliography to understand important points of theory
- Learned and getting used to use cleanroom tools
- Set up an experimental protocol
- Learned to cool down and warm up a dilution cryostat
- Made measurements at room and low temperature
- Exploited and interpreted the results

Thank you for your attention !

If you have any questions please ask.