


Basic Resist Theory


Basic Resist Theory



Contents

- **Electron scattering in resist and substrate**
- **Proximity effect**
- **Resist interactions (positive /negative/chemically amplified resists, resist contrast)**
- **Dose definition**
- **Influence of beam energy (penetration depth)**
- **Resolution limits**

Monte Carlo Simulations




Mag = 132.12 K X 200nm EHT = 0.52 kV Signal = 1.000 Signal A = InLens Date = 12 Jan 2004
GEMINI SUPRA 55 VP WD = 4 mm Image Pixel Size = 2.5 nm Signal B = InLens Time = 10:55:42
File Name = Preb1-10.tif

1.4µm PMMA on Si-substrate

Resist and Substrate Interactions of e-beam

Basic Resist Theory



Forward scattering events

- very often
- scattering under **small angles**
- small-angle hence **inelastic**
- generation of Secondary Electrons with a few eV kinetic Energy

Backward scattering events


- occasionally
- scattering under **large angles**
- large angle hence **mainly elastic**
- high kinetic energy, range of the primary electrons

electrons with typical **few eV** kinetic energy are **responsible for** most of the **resist exposure**

exposure by secondary electrons (SE_I and SE_{II})

Fragmentation of PMMA

Basic Resist Theory



Positive and Negative Resist

Positive Resist:

Average molecular weight reduced by exposure


→ exposed area is solved much faster in developer and thus removed

Negative Resist:

Average molecular weight increased by exposure (cross-linking of molecules)


→ unexposed area is removed in developer

Clearing Dose





1. Dose independent of resist thickness

2. Dose depends on beam energy




Proximity Effect



Proximity effect


- depends on beam energy, substrate, pattern
- various strategies for proximity correction, for example dose variation

Scattering Range Versus Energy



Resist Contrast

Resist contrast = Slope in resist



$$\text{Contrast } \gamma = [\log_{10}(D_1) - \log_{10}(D_0)]^{-1}$$


(Mark A. McCord, Introduction to Electron-Beam Lithography, Short Course Notes Microlithography, 1999, SPIE's International Symposium on Microlithography 14-19 March, 1999; p. 22)

Chemically Amplified Resist

Chemically amplified resists, are modified during exposure. However the final exposure takes place during the post exposure bake, when the acids are activated.


Example: SU8

SU8 resist



prebake

**chemically amplified resist:
postexposure bake**



postbake

- chemically amplified resist
- for 3D lithography:
used without postexposure bake

Resist Contrast

Resist	Energy	Developer	Stopper	contrast
ZEP520A	20keV	MIBK:IPA (1:1), 30s	IPA, 30s	1.1*
ZEP520A	10keV	MIBK:IPA (1:1), 30s	IPA, 30s	2.1*
PMMA	20keV	pure MIBK, 2 min	IPA, 30s	16***
ma-N 2400	20keV	MIF 276, 120s	DI-H ₂ O, 3-5 min	-1.7**
ma-N 2400	20keV	MIF 276, 240s	DI-H ₂ O, 3-5 min	-2.3**
SU-8 (no post exposure bake)	20keV	SU-8 developer (MicroChem)	IPA, 60s	-0.54*

* Raith GmbH, internal information

** http://www.nanophys.kth.se/nanophys/facilities/nfl/resists/ma-N240X-pdfs/13-MicroEngin_elsner.pdf

*** Rishton et al., JVST B **5** (1), 1986, pp.135-41

Resist Contrast

High contrast:

- + Steeper side walls
- + Greater process latitude
- + Better resolution
- + Less sensitivity to proximity effects

Low contrast:

- + 3d lithography

Example: 3D Lithography

Basic Resist Theory

Resist:


PMMA_50K

Resist thickness:


1.8 μ m

Development:


2.5min MIBK



German Museum, Munich



Calculation of Dose



I_{beam} = beam current

T_{dwell} = dwell time

s = step size

$$\text{Dose (Energy)} = \frac{I_{\text{beam}} \cdot T_{\text{dwell}}}{s^2} \quad [\mu\text{As}/\text{cm}^2]$$


Dose Table for PMMA (950k)

	10 kV	20 kV	30 kV
Areas	100 $\mu\text{C}/\text{cm}^2$	200 $\mu\text{C}/\text{cm}^2$	300 $\mu\text{C}/\text{cm}^2$
SPLs	300 pC/cm	600 pC/cm	900 pC/cm
Dots	0.1 pC	0.2 pC	0.3 pC

(developer: MIBK + IPA, 1:3)


The above values are good starting points. The best way to get optimum results is to perform a dose scaling: SPLs 0.5 – 5, Dots 0.1 – 10

Dose Versus Voltage



- *Increase of dose with voltage for all resists*
- *Graph shows general behavior*

Design must be adapted to dose



Johannes Kretz, Infineon, Munich

Influence of Beam Energy

100 keV

- + Small scattering in resist
- + Small proximity effect
- High beam damage
- strong sample heating


20 keV

- + Small beam damage
- + Small sample heating
- + Best electron-optical performance (classical columns)
- Scattering in thick resist
- Strong proximity effect

2 keV

- + No beam damage
- + No proximity effect
- + High throughput (high resist sensitivity)
- High scattering in resist
- Needs very thin resists

Penetration Depth Versus Energy



Y. Lee, W. Lee, and K. Chun 1998/9, A new 3 D simulator for low energy (~1keV) Electron-Beam Systems

Resolution Limits

Beam resolution

- Thick resists (forward scattering)
- Thin resists (~0.5nm by diffraction, de Brogli wavelength)

Resist limits

- Polymer size (~5-10nm)
- Chemically amplified resists (acid diffusion ~50nm)

(Mark A. McCord, Introduction to Electron-Beam Lithography, Short Course Notes Microlithography, 1999, SPIE's International Symposium on Microlithography 14-19 March, 1999; p.63)


Resolution Limits

Secondary electron range (~5-10nm)

In practice, the best achievable resolution in polymer resists is about 20nm, with inorganic resists (currently impractical for most applications) 5nm.

(Mark A. McCord, Introduction to Electron-Beam Lithography, Short Course Notes Microlithography, 1999, SPIE's International Symposium on Microlithography 14-19 March, 1999; p.63)

What is Possible ?



Ultra high resolution in PMMA (45nm thickness):
16nm line width in resist